



EJ VICTOR

AS YOU LIKE IT


STEP 1 Choose Your Arm Style




Lawson Arm




English Arm



Track Arm




Wide Track Arm




Cut Back Arm
(Not Available with T-Cushion)

STEP 2 Choose Arm and Seat Depth




Extended Arm
 38" Depth
 40" Depth




T-Cushion
 38" Depth
 40" Depth

STEP 3 Choose Back Pillow Style




Loose Knife Edge Weltless




Loose Box Edge Weltless


STEP 4 Choose Base Style




Dressmaker Skirt




Standard Base
(Accepts Front Legs 1-9)




Full Base
(Accepts Front Legs 10-13)



Kick Pleat Skirt



Serpentine Base
(Accepts Front Legs 1-9)



Floor Base
(Accepts Legs 14)

STEP 5 Choose Leg Style

